



1994-2001 Acura Integra Coolant Replacement

A video tutorial on how to change the coolant on a 1994-2001 Acura Integra by the drain and refill method.

Written By: eCuration



INTRODUCTION

The engine coolant should be replaced every 30,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.



TOOLS:

- [Spill Free Funnel](#) (1)



PARTS:

- [Engine Coolant](#) (1)

To reassemble your device, follow these instructions in reverse order.