



2005-2012 Toyota RAV4 Spark Plug Replacement

A video tutorial on how to change the spark plugs on a 2006-2008 Toyota RAV4.

Written By: eCuration



INTRODUCTION

If you are experiencing engine misfires, trouble starting, and or loss of power then it may be time to replace the spark plugs.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.

Torque specs:

- 14 ft. lbs - spark plugs
- 8 ft. lbs - ignition coil bolts

Safety

If this is your first time working on a vehicle read our [safety tips](#) before proceeding.



TOOLS:

- [3/8" Drive Ratchet](#) (1)
- [10mm Deep Socket](#) (1)
- [3/8-Inch Drive Extension Bar](#) (1)
- [Spark Plug Socket](#) (1)
- [Anti-Seize Lubricant](#) (1)
- [Dielectric Grease](#) (1)
- [Spark Plug Gap Gauge](#) (1)
- [Torque Wrench](#) (1)



PARTS:

- [Spark Plug](#) (4)

To reassemble your device, follow these instructions in reverse order.