

AXIOO Pico M1110 PJM Battery Replacement

Replace the battery.

Written By: Cakra Diaz



Step 1 — Underside



- Identify the battery locker.
 - Set the righthand locker to unlock.
- Pull the battery while setting the lefthand locker to unlock.

Step 2



Remove the battery.

To reassemble your device, follow these instructions in reverse order.