



Shark NV352 HEPA Filter Replacement

This is a guide on how to replace your HEPA filter for the Shark NV352 vacuum.

Written By: Amy Moran



INTRODUCTION

The HEPA filter is an air filter that traps harmful particles, such as pollen or dust. If it has been over a year or there is a bad odor when you use your vacuum, it might be time to replace the filter. Follow these steps to remove your filter either to clean or replace it.

Step 1 — HEPA Filter



- Put two or three fingers under the tab located at the bottom of the HEPA Filter.
- Push upwards on the tab at a slight angle to take off the cover.

Step 2



- Grasp the HEPA filter at the top and bottom and pull it slightly upwards to remove it.

To reassemble your device, follow these instructions in reverse order.