



Hoover Windtunnel Air Steerable Upright Suction Hose Replacement

This guide will assist you with breakdown and replacement of the suction hose.

Written By: steven hoover



INTRODUCTION

This guide will help assist you with removing and replacing the suction hose on your Hoover UH72400.

TOOLS:

- [Fingers](#) (1)
-

Step 1 — Suction Hose



- Turn the power off and unplug the power cord.
- Set the cleaner in the upright position.

Step 2



- Dislodge hose from plastic clips for ease of removal.

Step 3



- Press firmly on the hose button and slide hose out.

Step 4



- Pull the hose out of the top of the vacuum.
 - ⓘ The hose is connected to the vacuum handle.
 - ⓘ The bottom of the hose should come out when the top of the hose is pulled away from the vacuum.

To reassemble your device, follow these instructions in reverse order.