



Logitech Harmony 950 Battery Replacement

If the battery to the remote is not working...

Written By: Blake Sanborn



INTRODUCTION

If the battery to the remote is not working properly, follow this guide to replace it.



TOOLS:

- [iFixit Opening Tool](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- ⓘ Make sure the remote control is powered off before starting.
- Use the Opening Tool to open the port cover at the bottom of the remote control.
- Bend the cover back to gain easy access to the screws.

Step 2



- Use the Phillips #0 Screwdriver to remove the (2) two 6mm screws.
- Pull the bottom cover off of the remote control.

Step 3



- Use the Phillips #1 Screwdriver to remove the (2) two 6mm screws.
- There should be a gap on each side to fit the Opening Tool. Use the Opening Tool to open the back cover (Soft Touch cover) using the gap.

Step 4



- Use the Opening Tool to lift the battery out of the case.
- Gently pull the cable out of the socket to unplug the battery.

⚠ Be careful not to damage any part of the remote when pulling the cable out.

To reassemble your device, follow these instructions in reverse order.