



Shark Navigator Lightweight Upright Dust Cup Replacement

This guide will show how to remove the dust cup from the Shark Navigator Lightweight Upright.

Written By: Kahye Yu



INTRODUCTION

The dust cup acts as a filter for the debris and is a crucial component for the vacuum. This guide will show a step-by-step procedure to properly remove the dust cup.

Step 1 — Dust Cup



- Press down on the black, rubber ballish button located on the top of the vacuum.
- Pull back simultaneous on the plastic handle and remove the dust container.

Step 2



- Press the plastic tab in, located on the front of the dust container.
- Pull up simultaneously on the plastic handle.

Step 3



- Remove the dust cup from the inside of the dust container.

Step 4



- Push in the red tab located on the side of the dust cup.
- Open the dust cup simultaneously with the cone-half pointing downwards.
- Separate the two halves.

To reassemble your device, follow these instructions in reverse order.