



Osmo Mobile Battery Replacement

The purpose of this guide is to provide a step-by-step walk-through on how to replace a broken DJI Osmo Mobile battery.

Written By: Ustena Safa



INTRODUCTION

A unresponsive device that does not turn on may need the battery replaced. With this guide, learn how to locate the battery compartment and replace the battery.



PARTS:

- [HB01-522365 Lithium Ion Battery](#) (1)
-

Step 1 — Battery



- Open the battery compartment by locating the bottom of the handle, and pushing the slider forward.

Step 2



- Take out the battery by pushing down on the red tab. The battery will release, and can be pulled out by using the attached black tab.

To reassemble your device, insert the new battery and follow these instructions in reverse order.