

Asus Q552UB-BHI7T12 Battery Replacement

This guide will help you replace the battery of the Asus Q552UB-BHI7T12.

Written By: Alexander Boettcher



INTRODUCTION

Replacing the battery is helpful when the battery will not hold a charge for an extended period of time. Make sure the computer is unplugged and turned off the entire time. For any other problems follow the device troubleshooting page here.



TOOLS:

Phillips #0 Screwdriver (1)

Step 1 — Battery



- Remove all ten screws on the back of the laptop to remove the cover.
- Remove the cover.

Step 2



• Disconnect the wires at the top of the battery by lifting on the tabs protruding out of the plastic frame.

Step 3



 Remove the four screws holding the battery in place, two on top and one on each side.

Step 4



- Gently lift out the battery by the side closest to the motherboard first.
- ⚠ Be careful of any extra wires that may have attached itself to the battery.

To reassemble your device, follow these instructions in reverse order.