



iPad Air 2 LCD / display Replacement

This video guide shows how to replace the display assembly for the iPad Air 2.

Written By: Alex Sander



INTRODUCTION

[For the official iFixit guide, click here.](#) This guide has been archived for historical purposes.

TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
 - [Tweezers](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — LCD replacement video



- Video guide with useful tips about LCD replacement.

To reassemble your device, follow these instructions in reverse order.