



Thrustmaster T Flight Hotas 4 J1 Screws on Joystick Handle Replacement

The J1 screws hold the exterior of the joystick together.

Written By: Aaron Banaga



INTRODUCTION

The goal of this guide is to show how to remove the J1 screws from the joystick exterior.



TOOLS:

- [JIS #1](#) (1)
-

Step 1 — J1 Screws on Joystick Handle



 Be sure to disconnect the controller from the power source before disassembling.

- Remove the four 15 mm J1 JIS head screws from the exterior of the joystick.

To reassemble your device, follow these instructions in reverse order.