



Dell XPS 14 L401X Battery Replacement

How to replace a faulty battery in the Dell XPS 14 L401X.

Written By: Mark



INTRODUCTION

If your laptop is suffering from a faulty battery, it might be time for a replacement. Make sure the laptop is completely turned off before attempting to replace the battery.




PARTS:

- [Dell XPS 14, XPS 17 3D, and XPS L701x 3D Replacement Battery](#) (1)
-

Step 1 — Battery



 Make sure that the laptop is shut off before attempting to remove any components from the device.

 The laptop in this example did not have a battery equipped.

- Locate the spring latch on the bottom of the device that will unlatch the battery.
- Hold the spring latch in the open position and pull the battery out of its recess.

For optimal performance, after completing this guide, [calibrate](#) your newly installed battery.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).