

Philips Phone CD295 Disassembly

Disassemble Philips Phone CD295 to clean the keyboard contacts

Written By: Keul





Step 1 — Philips Phone CD295 Disassembly



• Open the back by sliding it down

Step 2



Remove the batteries and the 3 screws

Step 3



- Separate the white part of the brown one with a steel plate.
 - Take care of the red cable of the back speaker
 - The spings of the battery can go trough the hole as shown in the second picture.
- Remove the 2 screws.

Step 4



• You have now access to the keyboard and can clean it.

To reassemble, follow instructions in back order