



HP 15-ay014dx Battery Replacement

Battery replacement for the Hp-15ay014dx.

Written By: Nathan Rapalus



INTRODUCTION

This guide will provide simple, easy to follow battery replacement instructions for your

Hp-15ay014dx.

Step 1 — Battery



 Disconnect device from power source and power down.

Step 2



- With the device turned upside down, use your index fingers to push the battery latches in towards each other.

Step 3



- ⓘ The latch on your left will stay at the inward position, while the latch on the right will slide back out.
- Gently grasp the battery and pull it back away from the device and yourself.

To reassemble your device, follow these steps in reverse order.