


Lenovo Yoga Tab 3 8 Kickstand Lock Replacement

Opening the back of the Lenovo Yoga Tab 3 8 and removal of the kickstand lock for replacement.

Written By: Nicklaus Krems



This document was generated on 2020-11-27 04:53:35 PM (MST).

INTRODUCTION


If you are following this guide, that means your kickstand lock is broken or causing you issues on your Lenovo Yoga Tab 3 8. Before starting to work on your device, it is advised to back up any important files just in case something happens. You will want to make sure you have the device powered off to prevent harming yourself or damaging your hardware. To make reassembly easier, be sure to avoid misplacing the small screws by keeping track of them as you go.



TOOLS:

- iFixit Opening Tools (1)
- Tweezers (1)
- Phillips #00 Screwdriver (1)
- Metal Spudger (1)

Step 1 — Back Cover







- Open the kickstand by pressing the release button in the center.
- Remove the identification sticker with a pair of tweezers to allow access to the two 2mm screws underneath.

Step 2



- Remove the three 2mm screws under the kickstand with a PH00 screwdriver.
- The third 2mm screw to the right may have an S sticker covering it which you can scrape off.

Step 3








- Starting along the edge opposite of the hinge, insert a plastic opening tool between the screen and the backing to begin separating the small clips holding the backing on.
- Work along the edge and then up the sides, separating the clips with the plastic opening tool.
- There is adhesive underneath the slot for the SD card so you will need to slowly apply some force to break the adhesive.
- As the back is separated from the device, be careful to not lose the power button. It may come loose and fall out.


Step 4 — Kickstand Lock



 Locate the four 2mm screws that secure the lock and remove them with a PH00 screwdriver.

This document was generated on 2020-11-27 04:53:35 PM (MST).

Step 5



 Pry the lock up with a metal spudger. There is adhesive holding the mechanism down. Carefully separate it using even pressure.

To reassemble your device, follow these instructions in reverse order.