



# Shop-Vac MC150A Filter Cage Replacement

Use this guide to replace the filter cage on the MC150A Shop-Vac.

Written By: Ngunlian



---

## INTRODUCTION

This guide will walk you through the process of replacing the filter cage on the MC150A Shop-Vac.

---



### TOOLS:

- [3.5mm Hex Key](#) (1)
-

## Step 1 — Unlatch the power unit assembly



- ❗ Before you begin, make sure to switch off the device and unplug it from the outlet.
- Unlatch the two side clips securing the power unit assembly to the tank.
- Remove the power unit assembly from the tank assembly.

## Step 2 — Remove the foam sleeve



- Slide the foam sleeve up from the filter cage to remove it.

### Step 3 — Unscrew the filter cage



- Use a 3.5 mm hex key to remove the two screws securing the filter cage.

### Step 4 — Remove the filter cage



- Remove the filter cage.

To reassemble your device, follow these instructions in reverse order.