



iRobot Roomba i7 Filter Replacement

iRobot Roomba i7 Filter Replacement guide.

Written By: Ricardo Pazos Rodriguez



INTRODUCTION


Is your iRobot Roomba i7 not picking up debris and/or leaving clumps of debris on the floor? If this problem is occurring, your filter might be clogged and needs maintenance. To solve this problem, you will need to remove and clean the filter from your device. This guide will help you remove and replace the filter from your iRobot Roomba i7.

The filter for the iRobot Roomba i7 is located in the removable debris bin towards the rear of the device. The filter prevents dust and debris from escaping the debris bin.

Before you begin using this guide, make sure that your Roomba is turned off and disconnected from the charging station, or Home Base.

Warning: Do not clean the filter with any type of liquid. This process will also be very dusty and can cause reactions in those with severe allergies.

Step 1 — Filter



- Flip the iRobot Roomba i7 so that the underside is facing upwards and the back is facing you.
- On the left side at the back press the release button for the waste bin.

Step 2



- Once the bin is removed, empty any waste into a trash can.
- Be careful while emptying. Dust may escape and cause allergies.

Step 3



- Locate the filter on the side of the bin.
 - Placing your fingers on the light grey area, pull the filter directly out of the bin.
- ★ If replacing the filter, follow these steps in reverse order.

Step 4



- To clean the filter, tap it on the inside of a trash can.
 - Be careful not to shake dust everywhere; it may cause allergies.
- ⚠ Do not clean the filter with any type of liquid.

To reassemble your device, follow these instructions in reverse order.