




Lenovo Yoga 710-15ISK Speaker Replacement

Remove and replace the speaker system for the Lenovo Yoga 710-15ISK.

Written By: Annette Limoges



INTRODUCTION



This guide will show you how to replace the speakers in a Lenovo Yoga 710-15ISK laptop. The speakers are not necessary for your laptop to function but are a nice feature to have as they allow sound to be produced without the assistance of headphones. Signs your speakers may need to be replaced are hissing, fuzz, and static sounds being produced at normal volume levels and getting worse when the volume is increased. Remember that you can plug external speakers or headphones into your laptop's 3.5mm jack before you finish your speaker replacement to continue to have sound.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Remove the four 2 mm screws from the battery using a Phillips #0 screwdriver.

Step 2




- Remove the connector between the battery and the motherboard by gently pulling the black plastic-coated part of the wires.

Step 3





- Remove the battery from the laptop.

Step 4 — Speaker



- Disconnect the speaker wires from the motherboard by gently pulling the white connector from its port.

Step 5



- Unwind the wires from the plastic hooks lining the case.
- Lift out the speakers to remove them from the laptop.

To reassemble your device, follow these instructions in reverse order.