



# Samsung Galaxy S21 Plus Front-Facing Camera Replacement

Use this guide to replace the front facing...

Written By: Dominik Schnabelrauch



# INTRODUCTION

Use this guide to replace the front facing camera on your Samsung Galaxy S21 Plus.

This guide was performed on the **SM-G996B/DS** (international) model. Other models have an additional antenna cable sitting in the edge of the midframe.

If you do not replace the adhesive seals when reassembling, your device will function normally, but will most likely lose its water protection.

You'll need replacement adhesive to reattach components when reassembling the device.

---

## TOOLS:

[iOpener](#) (1)  
[Suction Handle](#) (1)  
[iFixit Opening Picks \(Set of 6\)](#) (1)  
[Heat Gun](#) (1)  
[Isopropyl Alcohol \(90% or Greater\)](#) (1)  
[Microfiber Cleaning Cloths](#) (1)  
[ESD Safe Blunt Nose Tweezers](#) (1)  
[Spudger](#) (1)  
[Phillips #00 Screwdriver](#) (1)  
[Tweezers](#) (1)

## PARTS:

[Galaxy S21+ Front Camera](#) (1)  
[Tesa 61395 Tape](#) (1)  
[iFixit Adhesive Remover](#) (1)

---

## Step 1 — Heat the back cover




- [Prepare an iOpener](#) and apply it to the back cover for at least three minutes to loosen the adhesive underneath.
- ⓘ A hair dryer, heat gun, or hot plate may also be used, but be careful not to overheat the phone—the display and internal battery are both susceptible to heat damage.

## Step 2 — Insert an opening pick



- Secure a suction handle to the bottom edge of the back cover, as close to the edge as possible.
  - ① If the back cover is cracked, the suction handle may not stick. Try [lifting it with strong tape](#), or superglue the suction handle in place and allow it to cure so you can proceed.
- Lift the back cover with the suction handle to create a small gap between the back cover and the frame.
  - ① If you have trouble creating a gap, apply more heat to further soften the adhesive. Follow the [iOpener](#) instructions to avoid overheating.
- Insert an opening pick into the gap you created.
- Slide the opening pick to the bottom left corner to slice the adhesive.
- Leave the opening pick in place to prevent the adhesive from resealing.

### Step 3 — Slice the adhesive



- Insert a second opening pick at the bottom edge of your phone.
- Slide the opening pick to the bottom right corner to slice the adhesive.
- Leave the opening picks in place to prevent the adhesive from resealing.

### Step 4 — Slice the adhesive



❗ If the adhesive becomes hard to cut, it has most likely cooled down. [Use your iOpener](#) for two to three minutes to reheat it.

- Insert a third opening pick at the bottom right corner of your phone.
- Slide the opening pick along the right edge of your phone to slice the adhesive.
- Leave the opening pick in the top right corner to prevent the adhesive from resealing.



## Step 5



⚠ When you slice near the camera assembly, insert only the tip of the opening pick (~4-5 mm) to avoid damaging or smearing the camera.

- Insert a fourth opening pick underneath the top right corner of your phone.
- Slide the opening pick along the top edge to slice the adhesive.
- Leave the opening pick in the top left corner to prevent the adhesive from resealing.

## Step 6



- Insert a fifth opening pick underneath the bottom left corner.
- Slide the opening pick along the left edge of the back cover to slice the remaining adhesive.


⚠ When you slice near the power button, insert only the tip of the opening pick (~3-4 mm) to avoid damaging the power and volume button flex cable.

## Step 7 — Remove the back cover




- Remove the back cover.
- ☑ During reassembly:
  - This is a good point to power on your phone and test all functions before sealing it up. Be sure to power your phone back down completely before you continue working.
  - Remove any adhesive chunks with a pair of tweezers or your fingers. Use some high concentration (over 90%) isopropyl alcohol to wipe away any adhesive residue.
  - If you're using Samsung custom-cut adhesives, [follow this guide](#).
  - If you're using double-sided tape, [follow this guide](#).

## Step 8 — Slice the adhesive



- ⚠ Take care not to puncture or bend the battery with your tool—a punctured or bent battery may leak dangerous chemicals or cause a thermal event.
- ⚠ Be careful of the cable that runs beneath the charging coil. Work slowly and stop sliding the pick if it catches on the cable.
- Insert an opening pick underneath the left bottom end of the NFC antenna and charging coil assembly.
- Carefully slide the opening pick along the bottom left edge of the assembly to separate it from the battery.


## Step 9



- Insert an opening pick underneath the bottom end of the NFC antenna and charging coil assembly.
- Carefully slide the opening pick along the bottom of the assembly to separate it from the loudspeaker.




## Step 10 — Disconnect the charging coil



- Use a spudger to disconnect the charging coil by prying the connector straight up from its socket.


## Step 11 — Disconnect the NFC antenna



- Use a spudger to disconnect the NFC antenna by prying the connector straight up from its socket.



## Step 12 — Unfasten the NFC antenna & charging coil assembly screws



- Use a Phillips screwdriver to remove the five 3.9 mm-long screws securing the NFC antenna and charging coil assembly.

## Step 13 — Remove the NFC antenna & charging coil assembly



- Use a pair of tweezers or your fingers to carefully remove the NFC antenna and charging coil assembly.

## Step 14 — Disconnect the battery cable



- Use a spudger to disconnect the battery cable by prying the connector straight up from its socket.


## Step 15 — Unfasten the earpiece speaker assembly screws



- Use a Phillips screwdriver to remove the seven 3.9 mm-long screws securing the earpiece speaker assembly.



## Step 16 — Disconnect the earpiece speaker



- Use a spudger to disconnect the earpiece speaker cable by prying the connector straight up from its socket.

## Step 17 — Pry up the earpiece speaker assembly



- Insert a spudger underneath the bottom left edge of the earpiece speaker assembly.
- Use your spudger to pry up the earpiece speaker assembly.




## Step 18 — Remove the earpiece speaker assembly



- Use a pair of tweezers or your fingers to carefully remove the earpiece speaker assembly.
- ☑ During reassembly apply new adhesive where it's necessary after cleaning the relevant areas with isopropyl alcohol (>90%).

## Step 19 — Disconnect the front facing camera




- Use a spudger to disconnect the front facing camera cable by prying the connector straight up from its socket.

## Step 20 — Loosen the front facing camera adhesive



- ① The front facing camera of the Galaxy S21 Plus is secured in place with an adhesive seal. It is not mandatory to replace this seal however the front facing camera will have a little amount of clearance if you don't.
- [Prepare an iOpener](#) and apply it to the screen where the front facing camera is located for at least two minutes to loosen the adhesive underneath.
- ① A hair dryer, heat gun, or hot plate may also be used, but be careful not to overheat the phone—the display and internal battery are both susceptible to heat damage.

## Step 21 — Remove the front facing camera



- Use a pair of tweezers to lift the front camera out of its recess and remove it.
- ☑ During reassembly apply new adhesive where it's necessary after cleaning the relevant areas with isopropyl alcohol (>90%).

---

If possible, turn on your device and test your repair before installing new adhesive and resealing.

Compare your new replacement part to the original part—you may need to transfer remaining components or remove adhesive backings from the new part before installing.

**To reassemble your device, follow these instructions in reverse order.**

After you've completed the repair, [follow this guide](#) to test your repair.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers community](#) for help.