



Disassembling Samsung Gear 2 Front half and Back half

Use this disassembly guide as a prerequisite guide to other replacement guides needing to access inside the Gear 2.

Written By: Jonathan Molina



This document was generated on 2020-11-25 01:46:09 AM (MST).


INTRODUCTION

This guide will walk you through how to disassemble the Samsung Gear 2.

TOOLS:

- [Spudger](#) (1)
 - [T5 Torx Screwdriver](#) (1)
-

Step 1 — Front half and Back half



- ✚ Before disassembling your Gear, be sure it is powered off.
- To remove each strap, locate the metal latches on both sides of the back of the Gear.
- Press down on the metal latch while pulling the strap away from the Gear until it is completely off.

Step 2



- Remove the four 4.0 mm screws on the back of the Gear using a T5 Torx Screwdriver.

Step 3



- Firmly holding the Gear, insert the flat side of the spudger at an angle to pry the back casing off of the device. Move the spudger along the sides of the Gear to completely detach the back and front components.
- Pry the device open from the other side also if it does not fully disassemble from one side.

To reassemble your device, follow these instructions in reverse order.