



# Lenovo IdeaPad Yoga 11S Top Assembly Replacement

Use this guide to expose all elements of the laptop such as the trackpad, RAM, Battery, and Display. In order to remove any of these parts, the top enclosure must first be removed.

Written By: Landon Epps



---

## INTRODUCTION




The top assembly contains the keyboard and trackpad. Removing it allows access to the logic board, battery, and RAM.


---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Top Assembly



 Remember to power off the device before removing any parts.

- Position the laptop so that the bottom enclosure is facing upward.
- Use a Phillips #0 Screwdriver to remove the ten 1.9mm screws holding the bottom enclosure in place.
- Use an opening tool to carefully pry up the rubber pads.
- Use a Phillips screwdriver to remove the two screws under the rubber pads, which secure the keyboard.

## Step 2 — Remove Keyboard




- Flip the laptop over and swing open the display.
- Lift the edge of the keyboard closest to the trackpad up.
- Carefully disconnect keyboard ribbon cable from the laptop.
- Remove the keyboard.

## Step 3



- Remove the two screws securing the midframe.

## Step 4



- Grab the front edge of the top assembly and lift it up carefully.
  - ⚠ There are three ribbon cables that attach the top assembly to the motherboard. Lift carefully to avoid damaging them.
- Gently slide the three ribbon cables out of their slots.
- Remove the top assembly completely by pulling it off of the device.

To reassemble your device, follow these instructions in reverse order.