



How to Fix A Warped Frisbee Disc

This guide will help you repair a warped frisbee disc back to its original shape.

Written By: Bryce Petersen



INTRODUCTION

For frisbee owners, a warped disc is a common problem due to prolonged sun exposure or moderate wear over time. For most discs, this warping can often be undone with some gentle manipulation. This fix involves a simple set up, and then letting the frisbee sit for approximately 1 hour.

TOOLS:

- [Towel](#) (1)
 - [Microwave safe bowl](#) (1)
 - [Textbook \(or large book\)](#) (1)
-

Step 1 — How to Fix A Warped Frisbee Disc



- Place the frisbee disc on a flat surface with the concave side facing up. Lay a towel down flat over the frisbee.

Step 2



- Take the bowl and fill halfway full with water. Microwave until water is boiling.
- ⚠ The bowl will be hot, so handle it with care.

Step 3




- Take the bowl with boiling water and place it on top of the frisbee and the towel.

Step 4



- Add a textbook as a weight to sit on top of the bowl.
- Let everything sit for 1 hour

Step 5



- Remove any weights, the bowl, and the towel. Check to see if the disc is still warped.
- ⓘ If it is still warped repeat this process one more time.

The time taken to fix the warping on your frisbee may vary based on how thick the plastic is.