


MacBook Pro 15" Retina Display Mid 2015 Logic Board Replacement

Use this guide to replace the Logic Board in...

Written By: Andrew Optimus Goldheart



INTRODUCTION

Use this guide to replace the Logic Board in your MacBook Pro 15" Retina Display Mid 2015.

Don't forget to clean and re-apply thermal paste if you remove the heat sink. Follow <u>this</u> guide to learn how.

TOOLS:

P5 Pentalobe Screwdriver Retina MacBook Pro and Air (1)

Spudger (1)

T5 Torx Screwdriver (1)

Tweezers (1)

Arctic Silver ArctiClean (1)

Arctic Silver Thermal Paste (1)

Coffee Filters or a lint-free cloth (1)

Isopropyl Alcohol 70% (1)

PARTS:

MacBook Pro 15" Retina (Mid 2015, Integrated Graphics) 2.2 GHz 16 GB RAM Logic Board (1)

MacBook Pro 15" Retina (Mid 2015, Integrated Graphics) 2.5 GHz 16 GB RAM Logic Board (1)

MacBook Pro 15" Retina (Mid 2015, Integrated Graphics) 2.8 GHz 16 GB RAM Logic Board (1)

MacBook Pro 15" Retina (Mid 2015, Dual Graphics) 2.5 GHz Logic Board (1)

MacBook Pro 15" Retina (Mid 2015, Dual Graphics) 2.8 GHz Logic Board (1) MacBook Pro 15" Retina (Late 2013-Mid

Step 1 — Lower Case



- Remove the following P5
 pentalobe screws securing the
 lower case to the MacBook Pro:
 - Eight 3.1 mm

2015) Screw Set (1)

Two 2.3 mm




• Lifting from the edge nearest the clutch cover, lift the lower case off the MacBook Pro.




- (i) The lower case has two plastic pegs (red) that fit into plastic clips in the upper case (orange).
- During reassembly, gently push down the center of the lower case to reattach the case to its two plastic clips.

Step 4 — **Battery Connector**




• Peel back the sticker covering the battery connector.




- Gently lift each side of the battery connector to pry the connector out of its socket on the logic board.
- Bend the connector back toward the battery, ensuring that the battery connector doesn't accidentally make contact with the logic board.

Step 6 — AirPort/Camera Cables




- Use a spudger or <u>tweezers</u> to pry the three AirPort antenna cables straight up off of their sockets on the AirPort board, and bend them up and out of the way.
 - The cable connection points are **very** fragile. Be careful to lift only on the connector, and not on the socket or cable.
- To reconnect, align the connector carefully into position over the socket, and press it down firmly with the flat of your spudger.


Step 7



• Peel the right rubber cover up off the fan and fold it out of the way.




- Use the tip of a spudger to push the camera cable connector out of its socket on the logic board.
 - (i) Be sure to push parallel to the board, pushing first on one side, then the other to "walk" the connector out of its socket.




- Use your fingers to pull the AirPort/Camera cables up off the fan.
 - ① The cables are adhered to the fan, so peel them up carefully to avoid damaging them.
- Carefully de-route the cables from the plastic cable guide.
- On reassembly, there should be enough adhesive still on these cables to stick them back down to the fan.

Step 10 — I/O Board Cable (Top)





Remove the four 2.2 mm T5
 Torx screws securing the I/O board cable connector covers.





- Remove the left connector cover.
- Use the flat end of a spudger to pry the left end of the I/O board cable up from its socket on the logic board.





- Remove the right connector cover.
- Use the flat end of a spudger to pry the right end of the I/O board cable up from its socket on the logic board.



- Peel the I/O board cable up from the adhesive securing it to the fan.
- Remove the cable.

Step 14 — Right Fan




- Use a T5 Torx driver to remove the following three screws securing the right fan to the logic board:
 - One 5.0 mm screw with a 2.0 mm long shoulder
 - One 4.0 mm screw with a wide head
 - One 4.4 mm screw


Step 15



• Use the tip of a spudger to flip up the retaining flap on the right fan ribbon cable ZIF socket.


⚠ Be sure you are prying up on the hinged retaining flap, **not** the socket itself.







- Lift the fan and push it gently towards the back edge of the MacBook to free the fan cable from its socket.
- The fan cable may be adhered to the logic board—to avoid tearing the cable, gently peel it up while lifting the fan.
- Remove the fan.

Step 17 — Left Fan






• Peel the left rubber cover up off the fan and fold it out of the way.




- Remove the following three screws securing the left fan to the logic board:
 - One 3.6 mm T5 Torx screw with a wide head
 - One 5.0 mm T5 Torx screw with a 2.0 mm long shoulder
 - One 4.4 mm T5 Torx screw

Step 19




• Use the tip of a spudger to flip up the retaining flap on the left fan ribbon cable ZIF socket.

⚠ Be sure you are prying up on the hinged retaining flap, **not** the socket itself.



- Lift the fan and push it gently towards the back edge of the MacBook to free the fan cable from its socket.
- The fan cable may be adhered to the logic board—to avoid tearing the cable, gently peel it up while lifting the fan.
- Remove the fan.

Step 21 — SSD



Remove the single 2.9 mm T5
 Torx screw securing the SSD to the logic board.



- Lift the end of the SSD up enough to pass over the speaker directly behind it. • Do not lift the SSD too high, or you could damage the contacts or socket.
- Pull the SSD straight out of its socket on the logic board.



- Use the point of a spudger to flip up the locking mechanism on the I/O board connector.
- Flip the spudger around and use the flat end to slide the I/O cable out of the connector.
- ② Push on the opened locking mechanism for an easy way to slide the I/O cable out of the connector. This could help prevent accidental damage to the cable or connector contacts.




 Remove the two 3.1 mm T5 Torx screws from the I/O board.



- Slightly lift the interior edge of the I/O board and pull it toward the center of the MacBook, away from the side of the case.
- Remove the I/O board.

Step 26 — Logic Board Assembly




- Remove the two 2.2 mm Torx T5 screws securing the touchpad cable connector cover to the logic board.
- Remove the cover.

Step 27




- Use the flat end of a spudger to disconnect the touchpad cable connector from its socket in the logic board.
- (i) Slightly twisting the flat end of a spudger is an easy way to pry up the cable connector from these types of sockets.


 \triangle Be careful to only pry up against the connector, and not the logic board socket.



• Remove a small rubber cap off the screw at the end of the heat sink.



- Remove the following six screws securing the logic board assembly to the upper case.
 - One 3.8 mm T5 Torx screw
 - Two 5.7 mm T5 Torx screws
 - One 5.6 mm T5 Torx screw (this one is silver and has a taller head than the others)
 - One 2.6 mm T5 Torx screw
 - One 3.2 mm T5 Torx screw
- On reassembly, start all six screws but do not tighten any of them. Move the logic board around until all of the screws are centered in their holes and the ports are lined up with their openings in the side of the upper case. Then tighten all of the screws.



- The following steps will detail disconnecting these six connectors. Be sure to read each step, as these connectors come in different styles that disconnect differently.
 - Microphone cable
 - Left speaker cable
 - Keyboard data cable
 - Right speaker cable
 - Keyboard backlight cable
 - Display data cable
- On reassembly, check to make sure all of these connectors are connected and fully seated in their sockets.



- Use the tip of a spudger to flip up the retaining flap on the microphone ribbon cable ZIF socket.
- Pull the microphone ribbon cable out of its socket, parallel to the logic board.


Step 32



 Use the flat end of a spudger to pry the left speaker connector up and out of its socket on the logic board.

⚠ Be sure to pry on the cable connector and not on the socket on the logic board. Prying on the socket may cause it to separate from the logic board.

• Gently fold the cable up and out of the way of the logic board.



• Peel back the tape covering the top of the keyboard data cable connector.


Step 34



• Use the tip of a spudger to flip up the retaining flap on the keyboard data cable ZIF socket.

 \triangle Be sure you are prying up on the hinged retaining flap, not the socket itself.

• Pull the keyboard data cable out of its ZIF socket. Be sure to pull parallel to the logic board, and not straight up.



 Use the tip of a spudger to pry the right speaker connector up and out of its socket on the logic board.

⚠ Be sure to pry on the cable connector and not on the socket on the logic board. Prying on the socket may cause it to separate from the logic board.

• Gently fold the cable up and out of the way of the logic board.

Step 36




 Use the point of a spudger to pry the keyboard backlight connector up from its socket on the logic board.




• Use the tip of a spudger to flip up the display data cable lock and rotate it toward the MagSafe 2 power port side of the computer.




- Pull the display data cable straight out of its socket on the logic board.
- \triangle Do not lift up on the display data cable, as its socket is very fragile. Pull the cable parallel to the face of the logic board.
- ⚠ Do not touch the contacts on the data connector or its socket with your fingers or any tools, as you may deposit oils or damage the pins.
- Gently bend the display data cable toward the display hinge, to expose the screws on the MagSafe 2 board.



 Remove the two 4.0 mm T5
 Torx screws from the MagSafe 2 board.









- Lift and pull the entire logic board assembly away from the wall of the upper case.
- ☑ When reassembling, be sure to line up the ports with their cutouts in the upper case.

Step 41 — Logic Board




- Use the tip of a spudger to flip up the metal retaining flap on the HDMI data transfer cable.
- Gently pull the HDMI data transfer cable straight out of its socket on the logic board.
 Just like the display data cable, be sure to pull the connector out of its socket parallel to the face of the logic board. Do not lift the connector up. Do not touch the connector.

Step 42



• Pull the MagSafe 2 connector straight out of its socket (parallel to the logic board).





Remove the single 2.9 mm T5
 Torx screw securing the
 AirPort board to the logic board.




- Lift the end of the AirPort board up enough to pass over the heat sink directly behind it.

 Do not lift the AirPort board too high, or you could damage the contacts or socket.
- Pull the AirPort board straight out of its socket on the logic board.
 - (i) There is a slightly adhesive thermal pad beneath the AirPort board. Be sure to reapply this when reinstalling the board.








- Remove the four 3.4 mm T5 Torx screws from the heat sink brackets.
- (i) These screws hold two springy heat sink brackets in place, which hold the heat sink against the CPU. They may spring up when you remove the first screw.
- Remove the heat sink brackets.

Step 46



- Remove the heat sink.
- On reassembly, be sure to clean the CPU and heat sink and reapply thermal compound to the CPU. Follow this guide to learn how.

To reassemble your device, follow these instructions in reverse order.