




Bosch 3727DEVS On/Off Switch Replacement

Purchase a new On/Off Switch. The sander should...

Written By: Peter Brouhle



INTRODUCTION

Purchase a new On/Off Switch. The sander should be unplugged from any power sources. Make sure you organize the removed screws, so you can reinstall them in the correct location.

TOOLS:

T20 Torx Screwdriver Bit (1)
Flathead 3/32" or 2.5 mm Screwdriver (1)

PARTS:

On/Off Switch (1)


Step 1 — On/Off Switch



 Ensure that the power chord is not plugged into an outlet.


- Using the T20 Torx Screwdriver, remove the four 15.6 mm screws securing the top cover to the sander.
- Lift the top cover off the sander.

Step 2





- Using the T20 Torx Screwdriver, remove the two 15.6 mm screws securing the cable clip to the motor housing.
- Lift the cable clip and cord from motor housing.

Step 3



- Using the [2.5 mm Flathead](#) Screwdriver, loosen the two screws securing the white and black wires to the On/Off Switch.

Step 4



- Remove the gray and purple wires by pulling on the wire terminals.

To reassemble your device, follow these instructions in reverse order.