

Ridgid Angle Grinder R10202 Carbon Brush Replacement

Use this guide to replace the two carbon brushes on your Ridgid Angle Grinder R10202.

Written By: Danielle De Castro



This document was generated on 2020-11-28 07:15:31 AM (MST).

INTRODUCTION

This replacement guide will walk you through how to remove and replace the two carbon brushes. You may also find this guide useful if you need to inspect the carbon brush housing for debris that may be hindering the device's performance.



TOOLS:

Flathead Screwdriver (1)



PARTS:

Carbon Brush Set (1)

Step 1 — Carbon Brush



Use a flathead screwdriver to unscrew the brush holder cap.

Step 2



- Using your fingers, gently lift the carbon brush up and out of its housing.
- Repeat these steps to remove the other carbon brush on the opposing side.

To reassemble your device, follow these instructions in reverse order.