


Nikon Coolpix L330 Image Sensor Replacement

The guide will replace the image sensor on a Nikon Coolpix L330.

Written By: Rajeev



This document was generated on 2020-11-27 08:23:27 AM (MST).

INTRODUCTION

The guide will assist in opening the camera, desoldering motherboard connections and replacing the image sensor.



TOOLS:

- Metal Spudger (1)
- Phillips #000 Screwdriver (1)
- iFixit Opening Tools (1)
- Screwdriver (1)

Step 1 — Back Housing







- There are six screws attaching the back housing to the camera. Remove the screws from the body with a PH000 screw head.
 - Two 1.5x2.5mm screws on the right side.
 - Two 1.5x2.5mm screws on the underside.
 - Two 1.5x2.5mm screw on the left side.





- After removing the screws, use a metal spudger or plastic opening tool to push the back cover out.
- The metal spudger can damage the plastic housing, so use caution when applying any pressure to it. Use a plastic opening tool to reduce the risk of damage to the housing.
- Remove the back housing of the camera by lifting it directly up.
- (i) The back cover may be slightly tight, therefore more force may be needed to lift it up.

Step 3 — LCD Screen





- Insert the tips of your fingers into the space between the screen and back-plate.
- Gently lift the screen up and out of the frame.

The screen is still held by a flexible display cable, therefore only lift the screen 0.5" out of the backplate.





- Tilt the screen so that the display cable forms a hinge with the backplate.
- Rotate the display 180 degrees so that it faces you.








- (i) The display cable has a ZIF (zero insertion force) connector on the end. This has a tab that has to be pushed out before the cable can be safely removed.
- Using a plastic opening tool or fingernail, pop up the black clip holding the display cable. This will release the cable.
- Slide the display cable out of the connector.
- The display cable can be damaged due to excessive bending, therefore avoid putting unnecessary strain on it.

Step 6 — Motherboard



- Remove the screws from the silver back-plate with a PH000 screw head.
- Two 1.5x2.5mm screws on the left side.
- One 1.5x2.5mm screw on the right side.



- The marked red box contains a highly charged capacitor. Check the charge using a voltmeter and discharge it first before continuing.

 <u>Discharge capacitor guide</u>.
 - Remove the screws holding the motherboard with a PH000 screw head.
 - Two 1.5x2.5mm screws on the right side.



- Using a plastic opening tool or fingernail, pop up the black clips holding the ribbon cables. This will release the cables.
- Slide the ribbon cables out of the connectors.








- Remove the black sticker covering the electrical connections.
- Desolder the eight wires from the motherboard.








- Insert a plastic opening tool into the marked position. Push the tool towards the right to release the clip.
- Using a thumb and forefinger, push the plastic cover up until it is at a 45 degree angle.
- Pull the cover back and up to release it.






- The motherboard is still held in place by soldered connections.
- Carefully desolder the connections .
- (i) The front cover has been removed in this picture, however the procedure is still the same.


Step 12




 Remove the motherboard by lifting it directly up.


Step 13 — Image Sensor





Remove the three 1.5x2.5mm screws using a PH000 screw head.





- Remove the three 1.5x1.75mm screws holding the lens in place using a PH000 screw head.
- Lift the image sensor up and out of the bracket.

To reassemble your device, follow these instructions in reverse order.