

AXIOO Pico M1110 PJM Keyboard Replacement

Replace the keyboard.

Written By: Cakra Diaz





TOOLS:

- Phillips #0 Screwdriver (1)
- Flathead 3/32" or 2.5 mm Screwdriver (1)
- Tweezers (1)

Step 1 — Underside



- Identify the battery locker.
 - Set the righthand locker to unlock.
- Pull the battery while setting the lefthand locker to unlock.

Step 2



Remove the battery.

Step 3 — Keyboard







- Identify these:
 - 4 keyboard clipper
- Remove the keyboard clipper by gently twisting them till pops out.
 - (i) Use a small flathead screwdriver to twist easier.
- Lift the keyboard up by pivoting on the bottom side.
 - ⚠ Don't lift it too high up, because beneath it there's the keyboard ZIF connector still connected; refer to the next step.

Step 4







- Identify this:
 - The ZIF connector locker
- Gently pull the locker out.
 - (i) Use a pair of tweezers to make it easier to pull it out.
 - ♠ Don't forget the other side too!
- Remove the ZIF connector.
- Remove the keyboard.

To reassemble your device, follow these instructions in reverse order.