



Replacing Motorola V60c Keypad and Keypad Logic Board

Author: Ryan Kuroiwa

Tools used in this guide

- [Plastic Opening Tools](#) (1)
- [T-6 screwdriver](#) (1)

Parts relevant to this guide

- [Motorola V60c Keypad](#) (1)
- [Motorla V60c Keypad Logic Board](#) (1)

How to replace the keypad and keypad logic board.



Step 1 — Battery

- Depress the silver button.
- Pull from top of phone to lift the cover.



Step 2

- Hold battery from both sides at the bottom.
- Push upwards and gently lift to remove.



Step 3 — Keypad and Keypad Logic Board

- Remove 4 screws from corners using T-6 screwdriver.
- NOTE: Bottom two screws are gold.
- NOTE: Make sure screws return to correct place when reassembling.




Step 4

- Use plastic opening tool to pry up back cover from two side clips.
- NOTE: Sticker might be attached to rest of phone.




Step 5

- Remove the back cover.




Step 6

- Use a plastic opening tool to gently remove the orange ribbon cable.
- Lift up the main logic board.
- NOTE: Rubber side buttons are not secure and might detach from the main logic board during removal.



Step 7

- Remove the keypad logic board.
- NOTE: Plastic spacer is not secured to keypad logic board and might detach during removal.



Step 8

- Remove the keypad.

To reassemble your device, follow these instructions in reverse order.