



Installing PowerBook G4 Titanium Onyx Airport Card

Author: iRobot

Tools used in this guide

- [T8 Torx Screwdriver](#) (1)

Parts relevant to this guide

- [Airport Card](#) (1)

Install an original Airport 802.11b card internally.



Step 1 — Lower Case

- Turn the G4 over.
- Remove the eight T8 Torx screws from the lower case.



Step 2

- Using your thumbs, slide the lower case away from you.
- The lower case may stick in the front on a tab just above the center of the DVD drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.





Step 3

- Your laptop should look approximately like this.



Step 4 — Airport Card



- Skip this step if your computer does not have an Airport card.
- Firmly grasp the plastic tab attached to the Airport card and pull up and to the left.
- Disconnect the antenna cable from the left side of the Airport card.





To reassemble your device, follow these instructions in reverse order.

This document was last generated on Feb 23, 2012.







Lower Case
8 T8 Torx



Hard Drive
2 T8 Torx



HD Replacement
2 T8 Torx



Modem
1 5mm Standoff

Logic Board (top)
1 T8 Torx

Logic Board
1 T8 Torx



Logic Board
2 T8 Torx





To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.

If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.

Due to model variations, the screws you remove may differ slightly from this guide.



PC Card Cage
1 T8 Torx

PC Card Cage
1 T8 Torx



Display (bottom)
4 T8 Torx



Display (top)
5 T8 Torx

Display (clutch covers)
4 T8 Torx

Display (ports)
4 T6 Torx

Display
4 T8 Torx

