



RIDGID R32104 Upper Blade Guard Assembly Replacement

Use this guide to replace the upper blade guard in your RIDGID R32104.

Written By: Lucas Pimentel



INTRODUCTION

Prerequisite only



TOOLS:



- [T20 Torx Screwdriver](#) (1)
 - [T50 Torx](#) (1)
-

Step 1 — Upper Blade Guard Assembly



- Maneuver the RIDGID saw, in order to easily remove the upper blade guard assembly.
- Using the T20 Torx Screwdriver, remove the four 4/10 cm screws that attach to the gear box.

Step 2




- Using the T50 Torx Screwdriver, remove the one 5/10 screw that attach to the gear box.

Step 3



- Using the T20 Torx Screwdriver, remove the two 4/10 cm screws that attach to the handle of the device.

Step 4



- Maneuver the saw to get to the base plate.
- Using the T20 Torx Screwdriver, remove the two 4/10 cm screws that attach the upper blade guard's base plate to the main housing assembly.

To reassemble your device, follow these instructions in reverse order.