




Replacement of the coin cell battery on the Dell XPS 13 9380

This guide explains how to replace the coin cell battery in your Dell XPS 13 9380.

Written By: Schwarzer



INTRODUCTION


You must disconnect or replace the coin cell battery in your Dell XPS 13 9380, this guide is for you!



TOOLS:

- [Mako Driver Kit - 64 Precision Bits](#) (1)
-


Step 1 — Remove the back panel



i Before you begin, be sure to turn off your laptop and unplug it from the outlet.

- Use a Torx T5 driver to unscrew the eight screws securing the back panel.
- Use a spudger to pry up and loosen the back panel.
- Lift the back panel up slightly from the non-hinged edge.
- Pull the back panel away from the hinged edge, wiggling it back and forth to loosen the clips.
- When the back panel clips are free, remove the back panel.

Step 2 — Remove the battery




- Disconnect the cable from the battery by pulling the connector towards the battery.

⚠ Pull parallel to the battery, not straight up.

- Remove the four screws (M2 x 2) securing the battery.
- Remove the screw (M1.6 x 4) securing the battery.
- Remove the battery from its recess.

Step 3 — Coin cell battery



★ We removed or disconnected the battery to avoid any electrical discharge.

⚠ **Removing the coin cell battery resets the BIOS settings to factory values. Before removing the coin cell battery, it is recommended to note the BIOS settings.**

- 1- Disconnect the coin cell battery cable from the motherboard
- 2- Use a lever to remove the coin cell battery from the motherboard.

To reassemble your device, follow the instructions in reverse order.