



Lenovo Yoga C930-13IKB SSD Replacement

With this guide, you can replace the SSD (Solid...

Written By: Hanna Lazkani



INTRODUCTION

With this guide, you can replace the SSD (Solid State Drive) currently in your Lenovo Yoga C930-13IKB laptop. An SSD is a newer kind of data storage device that does not have any moving parts, unlike the common Hard Disk Drives (HDD). SSDs are faster, more durable, and use less energy. The SSD can be replaced if it is faulty or if you would like to upgrade it.

The SSD card is easy to access and remove. You only need to remove the back cover to access the SSD, and then remove the fasteners attaching the SSD to the motherboard. For this guide, you will need a plastic opening tool, a T5 Torx screwdriver, and a Phillips #00 screwdriver.

TOOLS:

[T5 Torx Screwdriver](#) (1)
[iFixit Opening Tool](#) (1)
[Phillips #00 Screwdriver](#) (1)

PARTS:

[Crucial P3 NVMe PCIe M.2 2280SS SSD](#) (1)
[Crucial P3 Plus NVMe PCIe M.2 2280SS SSD](#) (1)
[Crucial P5 Plus PCIe M.2 2280SS SSD](#) (1)
[01FR544 - Lenovo SSD 256GB](#) (1)
[01FR539 - Lenovo SSD 1TB](#) (1)
[01FR537 - Lenovo SSD 256GB](#) (1)
[01FR538 - Lenovo Laptop SSD 512GB](#) (1)
[01FR511 - Lenovo Laptop SSD 512 GB](#) (1)
[01FR548 - Lenovo SSD 2TB](#) (1)
[01FR510 - Lenovo Laptop SSD 1T](#) (1)

Step 1 — Back Cover



- Flip the device over so that the underside is facing up.
- Remove the six 3.5 mm T5 Torx screws.

Step 2



- Pry off the back cover using the plastic opening tool.
- Loosen the back cover in multiple spots using the opening tool, then remove the whole back.
- ① You may have to run the plastic tool along the edges until you find a small gap to separate the back cover from the laptop.

⚠ Do not use a metal tool when working with your device.

Step 3



- Carefully lift the cover off with your hands.

Step 4 — SSD



- Remove the screw (2 mm with a 5 mm head) that connect the SSD to the motherboard using a Phillips #00 screwdriver.

Step 5



- Pinch the left side of the SSD card.
- Pull gently to the left, horizontal to the laptop.

To reassemble your device, follow these instructions in reverse order.