



Hamilton-T1 Battery Replacement

How to replace the hot-swappable battery in the Hamilton-T1 Ventilator.


Written By: Amanda Olla



INTRODUCTION


If you need to replace the optional second, hot swappable battery in your Hamilton-T1 ventilators, follow this guide. The hot-swappable battery is a secondary battery that provides power to the Hamilton-T1 ventilator when the standard primary battery runs out of charge or there is no external AC/DC power source available. This is a simple replacement to swap out the old battery with a charged battery. There are no tools involved.

Step 1 — Battery




- Use the handle on the left side of the front panel to pull the cover off.

Step 2



- Locate the metal lock clip above the battery on the left-hand side.
- Turn the metal lock clip to the left and all the way up.
- This will allow access to the battery.

Step 3




- Pull the white tab on the end of the battery to pull it out of the slot.

Step 4



- Insert the replacement battery by holding onto the white tab and sliding it into the empty slot.
- The Hamilton Medical logo needs to be facing up.

Step 5



- Turn the metal locking clip down and to the right, until it forms a straight line.

Step 6



- Close the cover.

To reassemble your device, follow these instructions in reverse order.