

How to Unclog a Shark Rocket Deluxe Pro Vacuum

How to unclog a Shark Rocket Deluxe Pro Vacuum (HV322) by removing obstructions, changing filters, and snaking the tube.

Written By: Savannah Webb



INTRODUCTION

If your Shark Rocket Deluxe Pro Vacuum (model number HV322) isn't rolling or sucking, chances are there's a clog inside the vacuum. Not all clogs are easy to see, so this guide will show how to troubleshoot all the major areas clogs can occur; inside the filters, the rollers, the dustbin, and the tube.

TOOLS:


- Utility Scissors (1)
- Microfiber Cleaning Cloths (1)
- Drain Snake (1)

Step 1 — How to Unclog a Shark Rocket Deluxe Pro Vacuum



• Press the wand release button to remove the vacuum body from the roller brush and wand.

Step 2



- Press the button at the bottom of the power cord on the dust bin.
- Pull off the attached piece.
- Remove the small filter from the piece.



• Pull the lever on top of the dust bin to expose the main filters.

Step 4



- Carefully squeeze and remove the top filter.
- Underneath that filter is a second filter. Pull the tab to remove it.



- Squeeze the release on the bottom of the dustbin.
- Remove the dust bin from the base.
- Pop the lid open using the slider.
- Empty the dust bin into the trash.

Step 6



- Rinse and wipe the plastic pieces removed earlier.
- Do not use soap.
- Set the pieces aside to air-dry.



- Place the filters in your sink and rinse out the dirt.
- Squeeze out any excess water and allow them to air-dry overnight before reinstalling.

▲ DO NOT USE SOAP.

Step 8



• With a wet rag wipe out any dirt buildup on the vacuum casing.



- Turn the base of the vacuum on its side.
- With your scissors, cut any wrapped hairs or strings that may be stuck on the rollers.

Step 10



• Lastly, insert your drain snake into the tube of the vacuum to dislodge any large stuck items.

To reassemble your device, follow these instructions in reverse order.