




Lenovo Yoga 710-15ISK RAM Replacement

This guide will show you how to replace the RAM...

Written By: Elisa Normand



INTRODUCTION

This guide will show you how to replace the RAM in your Lenovo Yoga 710-15ISK laptop. The memory of your laptop is an essential component that determines how many programs can be running at once. If you find your laptop is running slowly, you may want to upgrade or replace your memory. When buying replacement RAM sticks, check your laptop's specifications to ensure it's compatible—RAM comes in a number of shapes and configurations, and getting the wrong kind will cause your RAM to run slower than it should or not at all.

TOOLS:

Phillips #0 Screwdriver (1)

Spudger (1)

Step 1 — Back Cover





- Flip your laptop over so the bottom is facing upwards.
- Remove ten 2 mm screws securing the back cover to the laptop using a Phillips #0 screwdriver.

Step 2






- Pry the back cover off of the laptop with your fingers.

Step 3 — RAM



- Use the spudger to detach the clips holding the RAM cover.
- Gently pry the RAM cover up off of the motherboard using the spudger.

Step 4



- Use fingers to pry apart the clips holding the RAM in place.
- Slide the RAM out of its slot.

To reassemble your device, follow these instructions in reverse order.