




# Vtech Innotab 3 Headphone Port Replacement

If there is no sound coming from headphones when connected to the headphone port it may need to be replaced.

Written By: Zach Diviney



## INTRODUCTION

In order to replace the headphone port grab yourself a PH00 screwdriver, a metal spudger, and a soldering kit.

- Before you begin disassembling the Vtech InnoTab 3, turn on your soldering iron. If working with others let them know that the soldering iron is on and to use caution.



### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
  - [Spudger](#) (1)
  - [Tweezers](#) (1)
-

## Step 1 — Rear Panel



- Slide the battery compartment door lock down.
  - While still holding the battery compartment lock down, slide the two battery doors outwards on either side of the device.
  - Carefully remove the batteries from the battery compartment.
- i** The standard option for the InnoTab 3 is four AA batteries. Vtech also offers a rechargeable battery online, but both battery options are removed from the device the same way.

## Step 2



- Remove the six 7.6mm screws found in the battery compartment using a PH00 screwdriver.




## Step 3






- i** There are three hidden screws on the back of the device, two at the top and one near the bottom.
- Using a nylon or metal spudger, remove the three caps that hide the screws.
  - Remove the 5mm screw near the bottom and the two 7.6mm at the top using a PH00 screwdriver.

## Step 4






- Carefully separate the back panel from the front panel revealing the motherboard connected to the front panel.

## Step 5 — Headphone Port



- On the front panel of the device, the headphone port is located at the bottom right corner of the device, opposite of the speaker.
  - Using tweezers, lift up to remove the headphone port from its holding.
- i** Be careful not to tug too hard when removing the headphone port for you may disconnect the wires from the solder

## Step 6



- Use tweezers to hold the four connecting wires away from the headphone port.
  - Desolder the four wires connected to the headphone port.
- i** This is a tricky step. Refer to this guide to learn how to solder: [How To Solder and Desolder Connections](#)

To reassemble your device, follow these instructions in reverse order.