




# Polaroid Automatic 100 Bellows Replacement

The bellows are the part of the camera that may...

Written By: Katie Miller



# INTRODUCTION

The bellows are the part of the camera that may be made of a material that is shiny and looks like the fluid part of an accordion.

---

## TOOLS:

Large Needle Nose Pliers (1)


Metal Spudger (1)

Phillips #0 Screwdriver (1)

Flathead 3/32" or 2.5 mm Screwdriver (1)


---

## Step 1 — Bellows




- Fully extend the bellows by lifting the #1 lever.
- ① Remove the camera cover in order to make the camera easier to work with.
- ☑ When collapsing bellows, press down on the metal frame above the bellows.

## Step 2



- Peel the two battery cable tabs off of the bellows.

## Step 3



- Remove one 15.5 mm flat head screw, with a [2.5 flathead](#) screwdriver.
- Remove two 2 mm flat head screws, with a 2.5 flathead screwdriver. Then carefully remove the cable cover.
- ① Use the focus bar to extend bellows even further to access screws easier with the screwdriver.




## Step 4




- Open the back cover by pushing the lever on the bottom towards the left.

## Step 5





- Remove the four 3 mm screws, which are attached to the lens of the camera, using a Phillips #0 screwdriver.
- ① To make the screws easily accessible, close the bellows by pushing on the metal frame.
- ★ When reassembling, orient the camera so that screws are screwed in downward and stay in place.

## Step 6



- Carefully use a classic wide metal spudger to bend the tabs of the bellows.

## Step 7



- Pull the bellow tabs back with long needle nose pliers.
- Remove the bellows.

To reassemble your device, follow these instructions in reverse order.