

Lenovo Yoga 2 Pro Trackpad Replacement

This guide will walk you through the replacement of your computer's trackpad. It requires fairly little technical knowledge and mechanical skills.

Written By: Thomas Simko



INTRODUCTION

The trackpad is the component that controls the movement of the cursor on the screen with respect to the gestures made by your fingers. In this guide you will be instructed how to remove the trackpad of your laptop. Whether it's completely broken or just dirty from eating too many Cheetos, this guide has you covered.



TOOLS:


- Phillips #00 Screwdriver (1)
- Tweezers (1)



PARTS:

Replacement trackpad (1)

Step 1 — Battery




- Please ensure that the laptop is turned off before beginning.
- Using a Phillips #00 screwdriver, remove the eleven 1/4" screws from the back of the laptop.

Step 2




 Gently unclip and lift off the back cover.

Step 3




 Using a Phillips #00 Screwdriver, remove the five 5/16" screws surrounding the battery.

Step 4



 Using either tweezers or your fingers, disconnect the black battery cable by pinching either side of the connector and pulling towards the battery.


Step 5





Remove the battery from the computer.

Step 6 — Trackpad



 Using a Phillips #00 screwdriver, remove the eight 1/8" screws surrounding the trackpad.

Step 7



 Using a sharp tool such as tweezers, lift up the black cover that is on top of the ribbon cable.

Step 8



 With tweezers, gently slide the ribbon cable out from under the connector.

Step 9





Lift the trackpad out of the computer.

To reassemble your device, follow these instructions in reverse order.