




Dell Inspiron 14-7437 Battery Replacement

This guide will show you how to replace the Lithium-Polymer Battery inside your Dell Inspiron 14-7437.

Written By: Travis Connolly



INTRODUCTION


The Lithium-Polymer Battery in this laptop is long lasting but if it were to stop holding a charge then replacing it is simple and fast.





TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [Spudger](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
-

Step 1 — Base Cover



 Power off your Dell Inspiron 14-7437 before disassembling.



- Remove the eight 4.5 mm screws on the back panel of the device using the Phillips 1 Screwdriver.
-  The two 4.5 mm screws in the center under the rubber mount cannot be removed, but can be loosened.

Step 2




- Pry open the back cover using a spudger and slide it along the under the cover.

Step 3 — Battery




- Remove the two 2.5 mm screws holding the battery in place using the J000 Phillips Head Screwdriver.

Step 4



- Disconnect the ribbon cables from the motherboard.

Step 5



- Lift up and remove the Lithium-Polymer Battery.

To reassemble your device, follow these instructions in reverse order.