



Lenovo ThinkPad Yoga 14 20FY Hard Drive Replacement

Follow these steps to replace your...

Written By: Richard Terre



INTRODUCTION

Follow these steps to replace your dysfunctional hard drive!



TOOLS:



- [iFixit Opening Tool](#) (1)



PARTS:

- [1 TB SSD](#) (1)
- [250 GB SSD](#) (1)
- [Crucial MX500 500 GB SSD](#) (1)
- [2 TB SSD](#) (1)

Step 1 — Back Cover



- Remove the indicated nine M2 x 6 mm nylon-coated screws using a Phillips head screwdriver.



i The screws do not come all the way out. Do not force them out.

Step 2



- After removing all of the screws, gently lift up on all covers to remove the back plate and reveal the interior of the device.

Step 3 — Hard Drive




- Once the back cover is exposed, remove the two screws holding the hard drive in place.

Step 4



- Remove the plastic encasing holding down the hard drive after screws are removed.
- ⓘ This is the plastic encasing covering the SATA connection on the hard drive. There will be another plastic encasing that will be required to remove in a later step.

Step 5



- Using two fingers, carefully remove the hard drive.

Step 6



- Carefully remove the plastic encasing surrounding the perimeter of the hard drive.


Step 7



⚠ This step requires the most precision. Forcefully using the prying tool to remove the SATA connector may damage the hard drive and the connection. Remove the connection slowly to a point where you can safely finish removing the connection with your fingers.

- Use a nylon spudger to remove the SATA connector from the hard drive.

Step 8



- After the SATA connection is removed, gently pop off the hard drive from its socket.

To reassemble your device, follow these instructions in reverse order.