




# Asus VivoBook S200E-RH13T73 Wifi Chip Replacement

If your VivoBook continues to fail to connect...

Written By: Shilo Stuart



# INTRODUCTION

If your VivoBook continues to fail to connect to the internet after troubleshooting the internet settings, you may need to replace the WiFi Chip.

## TOOLS:


Metal Spudger (1)

Tweezers (1)

JIS Driver Set (1)


Phillips #0 Screwdriver (1)

## Step 1 — Wifi Chip



- With the screen closed, place your laptop upside-down with the front facing you.
- Remove the five black 80mm Phillips #0 screws.
- Remove the four black 50mm Phillips #0 screws.

## Step 2



- Use a metal spudger to pry the bottom panel open.
- ⚠ Be gentle around the edges.
- Lift the back panel to expose the inside of the laptop.

## Step 3



- Use a Phillips J0 screwdriver to remove the one black 3mm screw.



## Step 4



- Use an up and away motion to pull the module out of its slot.

## Step 5



- Use precision [tweezers](#) to pry the black wire with a gold plug off the main gold plug on the module.

---

To reassemble your device, follow these instructions in reverse order.

