


LG VX6100 Speaker Replacement

Written By: Ryan Bishop



TOOLS:

Desoldering Braid (1)

Phillips #00 Screwdriver (1)

Large Needle Nose Pliers (1)


Push Pin (1)

Soldering Iron (1)

Tweezers (1)

iFixit Opening Tool (1)

Step 1 — Front Case




 Remove the four grey plugs using either tweezers or a push pin.

Step 2



- Remove the four screws that are now exposed using a Phillips #00 screwdriver.
- i Be sure to put the screws in a safe place as they are very small and easy to lose.

Step 3




- Once all the screws have been removed, use a plastic opener tool to pry the case from the rest of the phone.
- Insert the opener tool into the seem between the case and the phone. Apply pressure to separate the two pieces.
- Do this across the entire length of the seem until the case is no longer attached to the phone.


Step 4



• The case can now be removed and the interior of the front is accessible.

Step 5 — Speaker





- Locate the four solder joints (connected to the yellow, black, blue, and red wires) on the bottom part of the phone, connected to the speaker. It will appear as a black circular part with some holes in it.
- Place a piece of solder wick on top of the solders.
- Very carefully, place the tip of the soldering iron on top of the solder wick. Hold it steady until the solder is soaked up into the solder wick.

⚠ Soldering iron will damage circuitry if held down for too long.

• Cut off the used solder wick with pliers and repeat this step if any solder remains.

Step 6



 After the solder has been removed, pry out the speaker with the plastic opening tool.

To reassemble your device, follow these instructions in reverse order.