

Acer Chromebook C710-2833 Fan Replacement

In this replacement guide, you will learn how...

Written By: Nicholas Latorre



INTRODUCTION

In this replacement guide, you will learn how to safely remove and install a cooling fan.

TOOLS:

64 Bit Driver Kit (1) Magnetic Project Mat (1) Anti-Static Wrist Strap (1)

PARTS:

Acer Chromebook C710 CPU Cooling Fan (1)

Step 1 — Fan



 Flip your Chromebook over so the bottom is facing up.


Step 2






- Locate the 6 mm Phillips #00 screw that holds the back cover together. Use your driver with the PH00 bit attached to unscrew it.
- Once completely unscrewed, carefully lift the cover off.
- Place the cover and screw safely to the side for now.

Step 3



- Now take your <u>anti-static wrist strap</u> and place it tightly on your wrist.
- Attach the alligator clamp of the wrist strap to something that will ground yourself to avoid possible electric zaps.
- *i* The location chosen in the picture is recommended.

Step 4





- Locate the two 6 mm Phillips #00 screws on the fan port.
- Unscrew the two screws and place them aside for now.

Step 5





- Carefully remove the fan from its port. You may need to use a little force as there will be an adhesive on the right side of the fan keeping it in place.
- Locate the Molex cable connecting the fan to its port in the top left corner.
 - Disconnect the cable.

To reassemble your device, follow these instructions in reverse order.